**TECHNICAL SHEET** 

No: T-20-0037

Page 1/2

# Sanitary supports for drain pipe

### **Product description:**

Sanitary support for drain pipe is construction element which is produced by compression molding and sheet metal sections of "C" shape. The metal profiles are attached to side plate-by welding and thus form two sliding spacers. To maintain the required resistance in humid environments, both structures are after welding protected with yellow (standard) or blue (on request) galvanized zinc. Fasteners provide attachment to the structure and fixing spacers.

#### Range of usage:

The product is used for mounting the double faucet and pipe into the vertical structure of the building. The bracket can be used in masonry, plasterboard or wood construction.

### **Characteristics:**

Material	Rolled sheet, drawn steel		
Coating	Yellow/blue zinc (ČSN ISO 4520)		
Thickness	3.00 mm <i>(ČSN EN 10143)</i>		
Reaction to fire	Class A1 <i>(EN 14195)</i>		
Durability	Class B		
Hazardous substance	NPD		








### **Product variability:**

Code	Name	Pack	Weight
TMD-0218 (1.348303 T)	RKB-40 support for pipe 40 mm	1 pc	0,89 kg
TMD-0219 (1.348304 T)	RKB-50 support for pipe 50 mm	1 pc	0,89 kg
TMD-0220 (1.348305 T)	RKB-63 support for pipe 63 mm	1 pc	0,89 kg
TMD-0221 (1.348306 T)	RKB-70 support for pipe 70 mm	1 pc	0,89 kg
TMD-0222 (1.348307 T)	RKB-90 support for pipe 90/110 mm	1 pc	0,89 kg

Real weight may vary in range of +/-5% according to ČSN EN10143

## **Mounting:**

Unpack the individual parts and assemble them according to the instruction manual. Put the complete structures into the prepared wall opening and stretch the brackets to whole width. Using the side plates and fasteners anchor the construction to CW profiles, masonry or wooden beams. Tight the safety screw to fix the bracer's movement. Set the location of sleeve by a water pipe and tight it as well. Block the opening so only the pipe input is visible. Finish the surface and attach the devices.





**TECHNICAL SHEET** 

No: T-20-0037

# Sanitary supports for drain pipe

### **Packaging:**

The sanitary support is packed unassembled in a carton box which is labeled with identification tag. The manual for mounting and assembly is included.

### **Recommended storage:**

The product is required to store in dry and temperate environment in order to prevent condensation on the surface of the product and damage to the packaging.

## Technical drawing:

